

# GERSON®

## Particulate Respirator 1845, R95

Nuisance Level OV-AG Vapors\*  
Full Foam Faceseal

**NEW!**



***NIOSH Approved R95 Particulate Respirator provides at least 95% filtration efficiency against solid and liquid aerosols, including oil based aerosols. Time use limitations may apply. Recommended for welding applications.***

- Layer of activated carbon provides comfort relief against *nuisance levels* of organic vapor, acid gas and ozone.\*
- Flame Retardant Outer Shell.
- Full foam inner gasket helps provide a good seal and is comfortable to wear.
- Heavy duty, adjustable head straps.
- Larger Comfort-Maxx™ valve opens more easily to expel hot, humid breath and keep inside of the respirator cooler and more comfortable.

### PACKAGING

ITEM NUMBER	NIOSH APPROVAL	MASTER PACKAGING	CASE WEIGHT	CASE DIMENSIONS	CASE CUBE	INNER BARCODE	CASE BARCODE
1845	R95	5/box, 50/case	15 lbs	26.75" x 17" x 14.75"	3.88 cf	0-44585-81845-2	5-00-44585-91845-4

\* "Nuisance Level" refers to concentrations not exceeding OSHA PEL or applicable government standards for exposure limits, whichever is lower.

**WARNINGS:** This product does not provide any lung protection against organic vapors or acid gases. Do not use in or around sandblasting. This product does not supply oxygen. Read and Understand Instructions and Warnings before using this product.

*Distributed by:*

**GERSON®**  
Leading the Way

© 2014 Louis M. Gerson Co., Inc. All Rights Reserved.  
16 Commerce Boulevard, Middleboro, MA 02346 U.S.A.  
Tel (508) 947-4000, Fax (508) 947-5442, Sales@GersonCo.com  
0725141